



1mm S/S tube makes a neat method of hooking the shroud (side stay) into the mast wall. Use 0.5mm S/S rigging wire and slide the 1mm tube over it and bend as shown. Leave about 30mm of wire stick through and bend as shown, this keeps it from un-hooking. Drill a 1mm hole, no bigger! 1mm S/S tube available from